



***EZ** converter*

APPLICATION SOFTWARE

User's Guide

Machine is allowed to read .ZHS format file which is transferred by any .PES, .DST and .EXP format files.

User operation screen is integrated with using GUI for tool bar and dropdown list options, the system platform which is including the main options of "file", "Edit", "View".

The software to which this User's Guide relates is subject to change without notice. All efforts have been made to ensure the accuracy of the contents of this User's Guide.


The software described in this book is furnished under a license agreement and may be used only in accordance with the terms of the agreement.

Contents

Starting the EZ Converter system.....	2
Basic Operation Map	2
Parts of the software window.....	3
Features of tool - File menu.....	5
Features of tool - Edit menu	6
Features of tool - View menu.....	8

Starting the EZ Converter system

Start Menu


1. Click the Start button at the bottom left of your desktop screen and the Start menu will appear.
2. Move the mouse arrow to All Programs and another menu will appear.
3. Click EZ Converter system folder.
4. Click on EZ Converter  to launch it.

Shortcuts on the Desktop


An alternative to the Start menu method described previously is to use a Shortcut to the program on your Windows® desktop. This is created automatically during the installation process if that option was selected.

1. Close or minimize any programs on your desktop screen.
2. A list of the programs will appear.
3. Double-click on EZ Converter to launch it.

Basic Operation Map



Parts of the software window



1. Title Bar

The title bar at the top of the window is highlighted if the EZ Converter System module is active. The title bar also contains the Minimize, Maximize and Restore icons, which may be used to control the size and visibility of the window.

2. Menu Bar

There are a number of menus in EZ Converter System module; all modules include File, Edit and View.

To access the menu options, use the mouse to pull them down from the menu bar.

3. Tool Bar

Provides shortcuts for the menu commands.

4. Embroidery Pattern Information

Displaying the detail information for the selected embroidery design, such as the total stitches, jump stitch, change thread...etc.

5. Embroidery Color Order Worksheet

The embroidery color order worksheet shows the thread colors have been setup for the selected design. Color orders are able to adjust by using the up/down arrows on the right side.

6. Status Bar

The status bar is found at the bottom of the window. Starting from the left, the status bar shows special information for that embroidery pattern, for the stitch size, zoom scale and stitch X/Y.

7. Hoop Size

Change the order of hoops, click the desired hoop in the list, then click the move up and move down buttons below the list.

8. Embroidery Area

The work area is the area where embroideries are loaded, it's the available area inside the selected hoop. The blue corners show the limits for embroidery inside the hoop.

Features of tool - File menu



Open

Opens a previously saved embroidery design file.



Save

Saves your embroidery design on the computer's hard disk as a latest version file.



Save As

Saves your embroidery design on the computer's hard disk under a new file name.



Close

Closes the current embroidery design file.



Import File

Imports embroidery designs files with different format (.PES, .DST and .EXP).

Page Setup

Allows you to change the printing settings for previewed embroidery design.



Print Preview

Allows you to preview your embroidery design before printing..



Print

Prints your embroidery design.



Exit


Exits the application.

Features of tool - Edit menu



Set Stitch Colors

The color of the objects for each color can be changed. The thread colors can also be changed in stitch. Click this button to open the set color window, that you can set the embroidery design stitch color.



1. Preview area

Review the selected embroidery design.

2. Color list area

List all colors for the selected embroidery design.

3. Thread Range box

Click the drop-down arrow at the end of the Thread Range box and choose the desired manufacturer's thread range from the list. The list of threads will change according to the chosen range.

4. Color setting area

Add the single color which the type exists in its number of the Find Thread box, or scroll through the color list to select it.



Set Fabric Color

Set the fabric color for embroidery whatever you prefer. Click this button to open the color window, that you can set the fabric color.




Set Stitch Length

This option is for Max. Stitch Length adjustment. The Max. length will be up to 12.7mm.




Rotate

Click this button to manually rotate the embroidery design by an arbitrary angle, you can type the desired rotation angle.




Flip Horizontal

Flips the selected embroidery design left/right.



Flip Vertical

Flips the selected embroidery design up/down.



Features of tool - View menu

Simulate


This option can be used for selected pattern simulation in advance before sewing. When click the button and the screen becomes blank for the working area.

Forward step by jump

Click to next step to begin the pattern stitch simulation. Each jump stitch change will be showing the needle moving procedure continuously until the design is completed.

Backward step by jump

This option can reverse the jump stitch action back to last step.



Zoom In


Click this button to zoom-in the embroidery design, the size will change 20% each time you press the button.

Zoom Out

Click this button to zoom-out the embroidery design, the size will change 20% each time you press the button.

Zoom Original

Click this button the embroidery design is displayed at its actual size.






Show Jump

Click this button to show the jump stitch of the embroidery design.



Normal view



Jump stitch view




Show Needle

Stitches view is also supported. Choose this option and the design pattern can preview the stitches view to know how the stitch is weaved.



Normal view



Stitches view

